


BACKUP SYSTEM 12 ou 24V



Define association between power supply / battery depending of Amps and hold time

Current (A)	Minutes					Hours						
	5	10	20	30	45	1	2	3	5	10	20	30
1	A	A	A	A	A	B	C	D	E	F	I	K
2	B	B	B	B	C	C	E	F	E	I		
3	C	C	C	C	D	E	F	G	H	K		
5	D	D	D	D	E	E	G	H	K			
7	E	E	E	E	E	F	H	J				
10	F	F	F	F	F	F	I					
15	G	G	G	G	G	G						
20	I	I	I	I	I	I						
25	J	J	J	J	J	K						

Current unsupported by the backup system

	12 VOLTS SYSTEM	24 VOLTS SYSTEM
A	ALE 1202 + BATT 1,3 Ah	ALE 2401 + BATT 1,3 Ah
B	ALE 2902M + BATT 2,1 Ah	ALE 2902M + BATT 2,1 Ah
C	ALE 2902M + BATT 3,2 Ah	ALE 2405 + BATT 3,2 Ah
D	ALE 1205 + BATT 4 Ah	ALE 2405 + BATT 4 Ah
E	ALE 1210 + BATT 7,2 Ah	ALE 2412 + BATT 7,2 Ah
F	ALE 1210 + BATT 10 Ah	ALE 2412 + BATT 10 Ah
G	ALE 1225 + BATT 15 Ah	ALE 2412 + BATT 15 Ah
H	ALE 1225 + BATT 17 Ah	ALE 2412 + BATT 17 Ah
I	ALE 1225 + BATT 20 Ah	ALE 2412 + BATT 20 Ah
J	ALE 1225 + BATT 25 Ah	ALE 2412 + BATT 25 Ah
K	ALE 1225 + BATT 30 Ah	ALE 2412 + BATT 30 Ah

Nota Bene : Power supplies and batteries are connected through MS 122402 backup system (except ALE 1225 & ALE 2412 beyond 10A)

